

CAPITALS FOR DURAGLASS 30" ROUND TAPERED COLUMNS

Ornamental capitals are set on top of the column astragal, and will affect the overall height:



Greek Erectheum



Greek Erectheum with Necking



Roman Corinthian



Roman Ionic



Scamozzi



Temple of Winds

Shaft nominal bottom diameter	Greek Erectheum				Greek Erectheum with Necking				Roman Corinthian		
	Capital height	Abacus width	Scroll width	Height adjust *	Capital Height	Abacus width	Scroll width	Height adjust *	Capital height	Abacus width	Height adjust *
30"	15"	31"	45 ½"	TBD	24 ¾"	31"	45 ½"	TBD	37 ½"	46 ½"	n/a

Shaft nominal bottom diameter	Roman Ionic				Scamozzi				Temple of Winds		
	Capital height	Abacus width	Scroll width	Height adjust *	Capital height	Abacus width	Scroll width	Height adjust *	Capital height	Abacus width	Height adjust *
30"	12 ½"	32"	40 ½"	TBD	12 ¾"	39"	33"	TBD	30"	39"	n/a

* "Height adjust" column is the adjustment to overall height when using this capital on a column trimmed for architecturally correct installation. DuraGlass Ornamental Capitals are not load bearing and will require a plug. Height shown does not include plug.