



## ORNAMENTAL CAPITALS FOR ARCHITECTURAL WOOD COLUMNS

Shaft Nominal Bottom Width	1 Empire			2 Empire w/Necking			3 Greek Eretheum			4 Scamozzi			5 Greek Eretheum w/Necking		
	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height	Scroll Width
6"	9	3 1/8	8 3/4	9	6 7/8	8 3/4	6 3/4	3 1/4	8 1/2	7 3/4	2 5/8	6 1/4	N/A		
8"	10	3 3/4	9	10	7 3/4	9	7 3/4	4 1/2	11 3/4	10 1/4	3	9	N/A		
10"	16	5 1/2	13 1/2	13 1/2	10	12 1/4	12	5 1/2	17 1/2	16	4 1/2	14	N/A		
12"	18	6 3/4	17	18	11	17	14 1/2	6 1/4	21	17 1/2	5	15 1/2	14 1/2	9 1/2	21
14"	20 1/2	7 1/4	19 1/2	20 1/2	14 1/2	19 1/2	15	7	21	19 1/2	6	16 1/2	15	11 1/4	21
15"	23	8 3/4	19 1/2	20 1/2	14 1/2	19 1/2	N/A			19 1/2	6	16 1/2	15	11 1/4	21
16"	23	8 3/4	19 1/2	23	17	19 1/2	17 1/2	9	26	22 1/4	6 1/4	18 1/2	17 1/2	13 1/2	26
18"	32	10	25 1/4	32	15	26 1/4	22	10 1/4	29	25	7 1/2	20 1/4	22 1/2	15	29
20"	34	11 1/4	28	34	17 1/4	28	26	11	36	28 1/2	8 1/2	24	26	17	36
22"	35 1/2	12 3/4	35	34	17 1/4	28	26	11 1/4	36 1/4	28 1/2	8 1/2	24	26	17	36
24"	35 1/2	12 3/4	35	35 1/2	19	35	30 1/2	13	43	34 1/4	10 1/4	29 1/2	30 1/2	19	43
26"	37	13	35	37	19	35	32 1/2	13	43	35 1/4	11	29 3/4	32 1/2	19 1/2	43
28"	N/A			37	19	35	31	15	45 1/2	39	12 3/4	33	31	24 3/4	45 1/2
30"	N/A			N/A			31	15	60 1/2	39	12 3/4	33	31	24 3/4	45 1/2
36"	N/A			N/A			N/A			46	15	38 1/2	N/A		

Shaft Nominal Bottom Width	6 Roman Corinthian		7 Roman Doric Ornamental		8 Modern Composite		9 Roman Ionic			10 Greek Angular Ionic			11 Temple of Winds	
	Abacus Width	Capital Height	Abacus Width	Capital Height	Abacus Width	Capital Height	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height	Scroll Width	Abacus Width	Capital Height
4"	N/A		N/A		N/A		N/A			N/A			6	6
6"	9 1/2	7	8 3/4	4	8	7	6 5/8	2 1/4	8 1/16	N/A			8	7
8"	12	8 1/2	13 1/8	6	10 3/4	8 1/2	8 1/4	3	10 1/2	9 1/2	3 3/4	9	10 1/2	7 1/2
10"	15	12	14 1/4	6 3/4	16 1/2	11 1/2	11	3 5/8	13 5/8	14 1/2	5 3/8	13 1/4	15 1/4	11 1/8
12"	18 1/2	14 1/2	16 1/4	7	19	14 1/2	12 1/2	4 1/2	16 1/2	17 1/4	6	17	16 7/8	11 3/8
14"	22	17	21	9	20	17	17 1/2	5 1/2	23	20 3/4	7 1/4	19 1/4	21 1/4	14
15"	22	17	24	10 1/2	20	17	17 1/2	6 1/8	22	20 1/2	8 3/8	19 1/2	21 1/4	14
16"	27	20	24	10 1/2	N/A		17 1/2	6 1/8	22	20 1/2	8 3/8	19 1/2	23	16
18"	32 1/2	23	28	12 1/2	25	22 1/2	20	6 1/2	24 1/4	24 1/4	9 3/4	19 3/4	26 3/4	18 1/8
20"	39	25 1/2	N/A		25	22 1/2	25	8 3/4	31 3/4	29 3/4	11	28	28	21 1/2
22"	42	28 1/2	N/A		N/A		25	8 3/4	31 3/4	29 3/4	11	28	34 1/2	23 1/4
24"	42	28 1/2	N/A		N/A		25 1/4	9	33	35	12 3/4	34 1/2	31 1/4	28 1/2
26"	42	32	N/A		N/A		26 1/2	9 1/2	33 3/4	39 1/2	14 3/4	38	35	24
28"	46	34	N/A		N/A		32	12 1/2	40 1/2	39 1/2	14 3/4	38	37	28
30"	46 1/2	37 1/2	N/A		N/A		32	12 1/2	40 1/2	N/A			39	30
36"	55	42	N/A		N/A		N/A			N/A			N/A	



Plaster Ornamental Capitals are coated with boiled linseed oil and turpentine as a temporary protector until they can be primed and coated with at least two coats of oil-base paint on the inside and outside. (If capitals are allowed to gather moisture before painting, peeling is likely to occur and further coating will be futile.) Ornamental Capitals are shipped with a load-bearing plug, which must bear the weight of any load on the column. Specifications and materials are subject to change without notice. Poly/Resin Capitals are load bearing, and do not require plugs.

Exterior and paint-grade interior columns feature polyurethane or fiberglass caps & bases (see charts) to provide crisp, true architectural detail and increased durability. Special-order wood caps & bases are available. Optional aluminum plinths provide an extra measure of protection.